



REFERENCE DRAWINGS	
ASSEMBLIES	NUMBER
2898 FLUSH VALVE ACCESS PANEL	9908-399-001

INSTALLATION INSTRUCTIONS:

A- ROUGH-IN FOR THE FOLLOWING CONNECTIONS:

- TOILET WASTE OUTLET ① 2-3/8" O.D. PLAIN END.
- 1" NPT THREADED MALE FLUSHING INLET ② CONNECTION.

B- POSITION TOILET ③ INTO FLOOR.

C- MAKE UP SUPPLY AND WASTE CONNECTIONS.

D- INSTALL FLUSH VALVE. RECOMMENDED MAX. DISTANCE IS 144".

NOTE: FIXTURE INCLUDES A REMOVABLE BAR ④ DIRECTLY OVER DRAIN.

E- USE DRAWING NUMBER 9908-399-001 TO INSTALL WALL SLEEVE AND ACCESS PANEL ⑤ SHOULD OPTIONAL 2898 FLUSH VALVE ACCESS PANEL BE REQUIRED.



TITLE 1699-W-3 DETOX TOILET: BLOW-OUT JET WITH REMOTE FLUSHING		
MANUFACTURE DATE FEBRUARY 1999 TO PRESENT	DATE ISSUED 02/17/99	DRAWING NUMBER 9925-046-002
	DATE REVISED 12/10/03	