



REFERENCE DRAWINGS	
-SW Wall Sleeve	9925-292-001
Mounting Hardware	9957-900-001

**INSTALLATION INSTRUCTIONS:**

- A-HAND TIGHTEN MOUNTING STUDS ① INTO MOUNTING NUTS ② ON BACK OF FIXTURE.
- B- POSITION FIXTURE ③ ON CELL SIDE, SLIDING STUDS ① THROUGH SLEEVE OR WALL OPENINGS.
- C- PLACE WASHERS ④ OVER STUDS ①. THREAD NUTS ⑤ TO STUDS ①, & TIGHTEN. DO NOT ALLOW STUDS ① TO TURN AND THREAD FURTHER INTO MOUNTING NUTS ②. NOTE: DO NOT EXCEED 6.5 FT/LBS MAXIMUM TORQUE ON 1/4" NUTS ⑤.

**ACORN ENGINEERING COMPANY**  
P.O. BOX 3527 INDUSTRY, CA. 91744  
(626) 336-4561 FAX (626) 961-2200

TITLE **REAR MOUNTED ACCESSORIES, CAT #1821, #1822, #1823, #1825, #1827, #1829**

MANUFACTURE DATE  
**DECEMBER 1971**  
**TO PRESENT**

DATE ISSUED  
**4/16/97**  
DATE REVISED

DRAWING NUMBER  
**9925-135-001**