




Option -WW



Water Waster Non-Sectional Controls -

The activation of a single hand or foot pushbutton activates all spray nozzles simultaneously. Option is shown with hand pushbuttons.

Please visit www.acorneng.com for most current specifications.

 WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

